

Zarge Ladders

Instructions covering assembly and use of 3-section multi-purpose ladders

Please note the instructions given in symbol form on the yellow sticker on the ladder. Particularly check the load capacity, stability and inclination, when using as a lean-to ladder or extension ladder. (figure 1)




Figure 1

1 Extending the multi-purpose ladder as a lean-to ladder

Catches are fitted to the lowest rung on ladder sections B and C, with lift safety device on ladder section C.




Figure 2

Before extending ladder section C, the safety latch must be pulled back and pivoted downwards. (figure 2)

Extend ladder to required length and place pair of catches on rung.

Pivot safety latch upwards and push under the rung of ladder section underneath it.

Ladder sections B and C can be removed and used as separate ladders. To achieve this, remove ladder sections by pushing down and out of the guides.



Gradav Hire & Sales Ltd

Unit C6 Hastingwood Trading Estate
Harbet Road, London N18 3HU

Phone 020 8803 7400 email office@gradav.co.uk
FAX 020 8803 5060 web www.gradav.co.uk

2 Assembly as a step ladder (figure 3)

Place unit vertically.

Release lift latch from ladder section C.

Slightly lift ladder sections B and C together and pivot outwards until the straps are taut.

Push out ladder section C and secure. (figure 2)

Re-folding of the multi-purpose ladder is achieved of course in the reverse order.




Figure 3

3 Assembly as step-ladder for use on stairs (figure 4)

Remove ladder section C from ladder section B.

Open up ladder sections A and B.

Turn ladder section C through 180 degrees. Place ladder section on inside of ladder section B and secure.




Figure 4



Gradav Hire & Sales Ltd

Unit C6 Hastingwood Trading Estate
Harbet Road, London N18 3HU

Phone 020 8803 7400 email office@gradav.co.uk
FAX 020 8803 5060 web www.gradav.co.uk